



MESTA ELECTRONICS, INC.

**Uninterruptible
Power
Supply**

Owner's Manual

MODELS: UPS1000, UPS1500, UPS2000

**SAVE THESE IMPORTANT
SAFETY INSTRUCTIONS**

11020 Parker Drive ■ N. Huntingdon, PA 15642
412/754-3000

Table of Contents

1. INTRODUCTION	1
2. GENERAL DESCRIPTION	2
3. INSTALLATION	4
4. OPERATING PROCEDURE	6
5. RS232 INTERFACE.....	7
6. STORAGE	10
7. INTERNAL MAINTENANCE	11
8. BATTERY INFORMATION	13
9. TROUBLESHOOTING.....	16
APPENDIX A. UPS SPECIFICATIONS BY MODEL.....	17
APPENDIX B. WARRANTY/SERVICE AND REPAIR.....	21

List of Illustrations

Figure 1: UPS Battery Tray Configuration	15
--	----

List of Tables

Table 1: UPS Software Parameters.....	8
Table 2: RS232 Technical Specification Summary.....	9
Table 3: RS232 9-Pin D-Connector Pinout.....	9

(Page Intentionally Left Blank)

1. INTRODUCTION

Thank you for buying the Mesta Electronics UPS! You are now an owner of a **TRULY UNINTERRUPTIBLE POWER SUPPLY**. No other system on the market can match your UPS.

SAVE THESE INSTRUCTIONS - This manual contains important instructions that should be followed during installation and maintenance of the UPS and its batteries. Please read this manual thoroughly before installation and operation of your new unit.

WARNING - Your UPS contains nine 12 volt batteries wired in series providing a total nominal DC voltage of 108 volts. This voltage is used to power the UPS when the AC utility is not available. Because of the presence of this high voltage energy source, even when the power cord is not plugged in, certain precautions must be taken to avoid possible injury should you need to unlock and enter your unit. Before attempting to unlock or enter your unit, read the sections of this manual on "**Internal Maintenance**" and "**Battery Information**" for important safety precautions.

WARNING - Always store the keys that unlock the unit in a safe place. DO NOT keep the keys in the lock of the unit where someone unqualified or unsupervised may inadvertently open the unit.

2. GENERAL DESCRIPTION

As computers become increasingly fundamental to today's businesses, protection against power disruptions has never been more critical; and since vital data and hardware are threatened by routine sags, surges, spikes, and transients -- as well as major blackouts -- protection must be constant and instantaneous.

The Mesta UPS system provides this kind of comprehensive protection by maintaining a clean, well-regulated flow of power to critical loads, regardless of the quality of incoming AC line power. It remains in a constant state of readiness, so there is no time delay in compensating for AC line failures.

Unlike many competitive units, the Mesta UPS system is **truly uninterruptible**. It remains in a constant state of readiness, so there is no time delay in compensating for AC line failures. In contrast, other systems may exhibit delays of 4 to 10 milliseconds -- long enough to cause serious losses of data or equipment.

Unique microcontroller intelligence plus state-of-the-art components and manufacturing procedures yield outstanding capabilities in the Mesta UPS system. Using a proprietary pulse-width-modulation technique, the microcontroller directs the system to produce a very low harmonic, high quality sine wave output -- perfectly matched in phase and voltage to the AC power line. The result is a completely seamless transfer of the load from the inverter to the utility and vice versa during a power disturbance or outage.

This zero-transfer-time feature, combined with a high frequency switching and custom magnetics, results in a high operating efficiency of at least 95 percent and a total harmonic distortion of less than one percent.

Because the microcontroller continually monitors the load and the power line, the Mesta UPS system:

- Starts under load with no damage to itself or the load.
- Handles nonlinear loads -- loads which require users of other UPS systems to buy more expensive, higher rated units than they would otherwise need.
- Provides current limiting and short-circuit protection. The UPS provides a 300% overload current limit for a finite time, and a short circuit placed directly across the output will not damage the UPS or the load, even if the power is coming directly from the AC line.

The Mesta UPS system also features:

- High Reliability thanks to the large scale integration and generous overrating of all power components. Its modular design provides for quick and easy maintenance should it ever be needed.
- A more compact footprint and lighter weight than ferroresonant UPS units, because of its custom transformer and intelligent operation.
- Quiet operation 1KVA through 2KVA units produce only 35 dBs of audible noise, a level that is virtually indistinguishable from ambient noise. (In contrast, most other similarly sized UPS units are many times louder, generating from 45-75 dBs.)

Straightforward controls make the Mesta UPS easy to operate, and audible and visual signals provide clear indication of system status. In the event of a power line outage, the system:

- Sounds an intermittent alarm after five seconds. (The five-second delay eliminates nuisance alarms from minor fluctuations.)
- Supplies power at maximum load for 7 to 20 minutes, depending upon model. (See specifications for your specific model.) These times will be longer at lesser loads or with back-up from external batteries.
- Sounds a continuous 30-second alarm when the usable battery has declined to 10 percent of its full capacity.
- Automatically goes into a state of inactivity once regulated output can no longer be maintained, waiting for the return of AC line availability. During this state of inactivity the logic will continue to look for the AC power to return in order to restore normal operation. If no AC power returns, however, after 2 hours the entire system will shutdown.

Once the AC power returns, the system's microcontroller employs optimum charging techniques to extend battery life while minimizing charging time. The microcontroller follows a unique algorithm by which it regulates the charging process and enables a minimal recharging time.

YOUR INVESTMENT IN MESTA'S TRULY UNINTERRUPTIBLE POWER SUPPLY INSURES THE VALUABLE POWER PROTECTION YOU NEED.

3. INSTALLATION

Unpacking: Before unpacking your unit, examine the shipping carton for damage. If there is any obvious damage, report it immediately to the dealer or carrier. If no damage is found, unpack the unit and inspect it for shipping damage. Again, in case of any damage, report it directly to the dealer or the carrier.

Environment: The MESTA UPS is designed to be used in an environment with a temperature range of 0-40°C and relative humidity of 0-95%, without condensation. The site should not be excessively dusty or dirty. Clearances should be provided to the front and back of the unit so as not to block air inlets and outlets. Also, keep the top of the unit clear of objects. The unit should never be used to sit or stand on.

Location of Unit: The UPS should be in close proximity to the protected equipment: the longer the AC wire runs, the more voltage drop and more risk of noise getting back into the system there are.

Voltage/Power Rating: Make sure that the voltage and power rating match the available line voltage and load requirements. This can be done by comparing the input and output information printed on the rating plate of the UPS with your requirements.

Power Cord Plug-in: Having verified voltage and power ratings, you are now ready to plug the UPS into the AC power. Your unit will either have a detachable power cord or one that is fixed to the UPS. (If you have a detachable cord, it was shipped with the unit. Only use this cord with your UPS. Do not substitute other cords in its place as their current ratings may not be sufficient for your UPS needs. Plug the detachable cord into the UPS input receptacle.) Now plug the AC power cord into the utility receptacle at your facility.

UPS Power On: Having plugged your UPS into the AC utility, you may now turn on your UPS using the front panel power switch. After a few seconds delay, the UPS will begin operating. Initially (for a very short period of time) all front panel lights will flash on simultaneously, and the audible alarm will beep once. Then the UPS will "power up" with the "UPS" red front panel light on. If the AC power utility is present and within tolerance of the UPS, the "AC LINE" green front panel light will also be on. After an additional couple of seconds, the "UPS" red light should go off, and the "AC LINE" green light should remain on, indicating that the UPS is able to derive power from the AC power utility.

Fault Checking: If the normal **UPS Power On** sequence does not occur for you, perform one of the following alternative actions:

- 1) If the "UPS" red light comes on and remains solidly on (also eventually to be accompanied by an audible beeping alarm), recheck your connections to the AC utility. (Also check to see if any breakers or fuses in that particular circuit of your building or in the back of your UPS are open.) If after rechecking no problem is found, and the UPS will not perform according to the proper procedure described above, contact the factory for further assistance.
- 2) If the normal **UPS Power On** procedure is not observed, and the warning conditions described in alternative #1 are also not observed, contact the factory for further assistance.

Connecting the Load: Assuming that normal operation was observed, you can now plug your loads into the receptacles at the back of the UPS. If during this procedure the "OVERLOAD" red light comes on or starts blinking along with an audible alarm, your load is too large for the UPS, and some must be removed or the UPS will shut down.

Installation Complete: Assuming an overload doesn't occur prior to attaching and turning on all loads, you have completed the installation procedure of your UPS. From here on there is no

special powering up or powering down sequence that needs to be followed for either your load equipment or the UPS. This installation procedure is only necessary to insure that the UPS did not incur any internal shipping damage and that your building's AC utility is getting to the UPS.

Computer Terminal Connections: It is also suggested, but not required, that you connect a terminal or computer to the RS232 interface (see section of the manual pertaining to this interface). Through this communications interface you can obtain additional useful data that is either very difficult to determine or is not available from the front panel lights. One of these parameters is the load on the UPS. The microcontroller will indicate the ampere and volt-ampere load on the UPS. From this information you will be able to determine if additional loads may be added in the future. It is advisable that the steady state load observed on the UPS be limited to a maximum of around 80 to 85% of the full rating of the UPS under normal operating conditions. This should provide enough margin under most operating conditions.

4. OPERATING PROCEDURE

SYSTEM TURN-ON

Once plugged in and turned on, the MESTA UPS will begin supplying power to the load. The green "AC LINE" and "BATTERY" lights will be on. If the AC line fails, the red "UPS" light will come on, and after 5 seconds an intermittent alarm will sound for 30 seconds. (This alarm may be silenced by pressing the "ALARM RESET" button on the control panel.)

The following are the conditions that are indicated by the light and beeping sequences:

AC LINE ON (green)	AC line within tolerance
BATTERY ON (green)	Solid -- over 90% charge Off -- discharged Flashing 75% dutycycle -- 50-90% charge Flashing 50% dutycycle -- 25-50% charge Flashing 25% dutycycle -- 25-10% charge Flashing 10% dutycycle -- 10-1% charge At this point a solid tone can be heard for 30 seconds.
UPS ON (red)	Solid, and after 5 second delay, 30 seconds of intermittent beeping -- drawing power from battery. Flashing with "OVERLOAD" on -- system shutdown due to overload. UPS needs attention. Flashing with "BATTERY" off -- system shutdown due to drained batteries. UPS needs attention.
OVERLOAD (red)	Solid and solid tone -- greater than 150% overload. Flashing and beeping -- 100-150% overload.

ALARM RESET button tests lights and alarms as well as silences alarm, except in case of an overload. It is also used to test the batteries.

To Test the Batteries: The UPS is programmed to test the internal batteries automatically and under load. The procedure for starting this 60 second test is to hold the "ALARM RESET" button in for at least 5 seconds. Release the button, then touch it again three more times in short succession. This will signal the microcontroller to begin testing the batteries. The UPS will start beeping to signal that the test is in progress. Test results will be indicated by the "BATTERY ON" light as indicated above. To obtain more precise test results, use the software interface provided with the system.

5. RS232 INTERFACE

For sophisticated applications the Mesta UPS system provides an RS232 communications interface which can link the microcontroller with a remote computer or terminal. This two-way link allows users to 1) collect detailed information on power usage and other characteristics of the load to which the UPS is connected and 2) remotely control the UPS or the load. (For example: a system can be developed to alert the computer to automatically save data and shut itself down when the UPS battery power is dwindling and no emergency generator is available.)

Any computer or terminal equipped with an RS232 serial port capable of a 1200 baud rate can be used to communicate with the UPS. If a terminal is being used, one can begin sending commands to the UPS as soon as a 3-wire hardware interface is in place. If a computer is being used, a communications software package that allows the computer to act as a terminal must be executed on the computer. Mesta provides this software on a 5 1/4" or 3 1/2" diskette. Once communication has been established with the UPS, the UPS will provide a ">" prompt, which signals the operator to enter a command.

Software Commands: UPS information may be examined using the following commands:

- Sn** **Status** command displays the present status of a parameter. To display the status of a particular parameter, type **Sn<cr>**. "S" indicates the status command, "n" represents a letter from A to L designating the parameter you desire to observe, and **<cr>** indicates a carriage return (or enter key) which is used to terminate the command. Table 1 contains the list of available parameters that may be examined. As an example, if the present AC line voltage is to be examined, one would type **SA** followed by striking the **<cr>** key. One can also just enter **S<cr>** with no parameter letter and obtain a status update of 11 of the most useful parameters all at once.
- Vn** **View** command is similar to the Status command except the View command will continually display the status of the selected parameter until one presses the escape key on the computer or terminal keyboard. To continually view the status of a particular parameter, type **Vn<cr>**. "V" indicates the View command, "n" represents a letter from A to L designating the parameter to be viewed, and **<cr>** indicates a carriage return (or enter key) which is used to terminate the command. Again, Table 1 contains the list of available parameters that may be examined. As an example, if the AC line voltage is to be viewed continuously, one would type **VA** followed by striking the **<cr>** key. One can also just enter **V<cr>** with no parameter letter and continually view the status of 11 of the most useful parameters all at once.
- <Esc>** The escape key can be pressed at any time to abort any command. After pressing the escape key, the UPS will display **<Esc>** to indicate such a key was pressed followed by a new ">" prompt. At such a time a new command can be entered.

Table 1: UPS Software Parameters

Letter to Use	UPS Parameter	Notes
A	AC line voltages (in RMS volts)	
B	UPS output voltage (in RMS volts)	
C	Battery voltage (in DC volts)	
D	AC line frequency (in Hertz)	
E	UPS output frequency (in Hertz)	
F	Battery charge remaining (percent)	1
G	UPS mode	
H	UPS output current (in RMS amperes)	
I	Current draw from battery (in DC amperes)	2
J	Fault status	
K	UPS volt-amp output (in volt-amperes)	
L	Temperature (in °C/F)	
M	Inverter DC voltage (DC volts)	
N	AC line amps (in RMS amps -- not true RMS)	
O	V-Amp rating	
P	Version	
None	Parameters A through L displayed all at once	

Notes on the MESTA UPS Parameters:

1. The accuracy of the percentage of battery charge remaining depends on operating conditions and the present loading of the UPS. The accuracy will be much more precise at the lower percentages than it is at the higher percentages (where the performance curve flattens and a perfectly correct interpolation is more difficult - in the 92-100% range).
2. Current draw from the batteries is "+" if batteries are being discharged and "-" if batteries are being charged. A small positive or negative value of .1 or .2 amps may not necessarily reflect that the batteries are being charged or discharged.

Changing the Programmable Parameters (FSET): To set the three parameters of 1) minimum output voltage, 2) frequency range allowed, and 3) slew rate (how fast you allow the output to change frequency), all of which are in the non-volatile memory, the incoming AC line must first be disabled. To accomplish this:

- Type **ACDIS < rtn >** to *disable* the incoming AC. The UPS will operate from the batteries when you do this.
- Then type **FSET < rtn >** to enter the *function set* routine, and the first of the three programmable function will appear on the screen with the question of whether you'd like to change this particular parameter.
- As you respond by typing a **Y** (yes) or **N** (no), the screen will then indicate the value range within which you can program the function.
- After programming the appropriate response for all three functions, the microcontroller will return a prompt. When the prompt appears, simply type **ACEN < rtn >** to *enable* the UPS to reconnect the utility's AC voltage. ***Don't forget this last step!***

Table 2: RS232 Technical Specification Summary

CONNECTOR:	9 pin D female
FORMAT:	ASCII, 1 start bit(0), 8 data bits, 1 stop bit(1)
BAUD RATE:	1200
PARITY:	none
DUPLEX:	full
PROTOCOL:	None used. Interface is simple 3 wire (RXDATA, TXDATA, and GND) with no hardware or software handshaking.

Table 3: RS232 9-Pin D-Connector Pinout

PIN 2:	Transmit Data
PIN 3:	Receive Date
PIN 5:	Signal Ground

6. STORAGE

Battery Life: The MESTA UPS should be stored with the batteries fully charged. MESTA Battery Packs should also be stored with the batteries fully charged. Storage temperature should be maintained between -20°C and 40°C. The life of the batteries may be greatly reduced if stored at temperatures exceeding 30°C for extended periods of time. Optimal storage temperature for maximum battery life is 20°C or lower.

Power Switch: Make sure the power switch to the UPS is off prior to storing the UPS. Also, batteries may be permanently damaged if not removed from storage periodically and fully recharged at least once every 6 months. To recharge batteries inside UPS, simply remove the UPS from storage and connect the unit to an AC power source for a minimum of 4 hours (make sure batteries are being charged by monitoring the LEDs on the front panel of the UPS -- it should be off). Then you may turn the unit off again and return it to storage for up to another 6 months. To recharge batteries in a battery pack purchased from Mesta, follow the directions to connect the battery cabinet to a Mesta UPS in the "**Battery Information**" section of this manual. Allow a minimum of 4 hours charging per battery cabinet.

7. INTERNAL MAINTENANCE

WARNING

Only qualified technicians or supervised personnel should open the UPS and only after ALL of the following WARNINGS and instructions are read and fully understood.

Mesta's UPS has been designed to provide unprecedented reliability; therefore it requires little or no maintenance. However, should internal maintenance be required, please adhere to the following warnings and instructions.

WARNING

Risk of **Electric Shock** exists inside the UPS. The UPS receives power from the AC source (via the AC power cord) and a DC source (via the internal batteries). Maintenance personnel must be aware of this hazard, or they may be exposed to an electrical shock hazard that could result in death or injury or damage to the UPS or its electrical loads.

WARNING

The UPS internally contains capacitive components which remain energized even after power to the UPS has been turned off. A unit's front panel LEDs are functioning normally such that when the unit is turned on, one or more of the LEDs lights up steadily or periodically, and when the unit is then turned off, all LEDs go off within 20 seconds. Under these circumstances the voltage across these capacitive components will be minimized to safe levels within 1 minute of turning the UPS off. If, however, the LEDs never come on or never go off during operating of the Transfer Switch, a problem exists with the unit. Under such conditions it is possible for hazardous voltages to remain for longer periods of time. If such a malfunction exists, it is advisable not to open the unit. Instead, contact the manufacturer or nearest repair center. A qualified technician will need to check the DC voltage across the buss bars that connect the large capacitors attached to the heat sink before proceeding with any internal maintenance. This voltage could be as high as 250 volts DC. One should wait until voltage is below 30 volts DC before proceeding. Otherwise, maintenance personnel may be exposed to an electrical shock hazard that could result in death or injury, or damage to the UPS or its electrical loads may occur.

Instructions for Opening and Closing the UPS: Before opening the unit from the front using its keys, make sure the UPS power switch is "OFF" and the AC power cord is unplugged. After all front panel LEDs go off, remove the external battery connector (should external batteries be plugged into the UPS). Next, remove the fuse labeled "INV" in the back of the unit by turning the fuse cap counterclockwise. Then pull out fuse/fuse cap, being careful to touch only the plastic cap while extracting the fuse. To avoid risk of **Electric Shock**, **DO NOT** probe into empty fuse holder. Only open unit from the front using the key. Turn key clockwise 1/4 turn and open front door. If desired, the top of the unit can also be removed for access. **DO NOT** try to enter the unit any other way (such as removing screws from back of unit) as such an action may result in risk of **Electric Shock**. If extensive work is to be done within the UPS, remove the battery trays from the

unit as described in the "**Battery Information**" section of this manual. When completed servicing inside of unit, close door, and lock unit by turning key 1/4 counterclockwise. After making sure power switch is still in the OFF position, place fuse cap on one end of INV fuse (if the two have become separated) and screw fuse/fuse cap clockwise into empty fuse holder, being careful to touch only the plastic part of the cap. If an external battery pack is being used, plug the battery connector back into the back of the unit.

8. BATTERY INFORMATION

The standard batteries supplied in the MESTA UPS are eighteen sealed lead-acid maintenance-free 12 volt 6.5 amp-hour batteries. These batteries are wired in series to provide a total nominal voltage of 108 volts DC. Expected battery float life is 5 years at room temperature (70° F), although frequent discharges and high ambient temperatures will shorten battery life. The standard battery supplied is designed to be kept at a constant 13.5 to 13.8 volts. The microprocessor is set to charge the batteries to 13.7 volts. It will recharge the fully discharged batteries in approximately 2 hours. The run time that one can expect is dependent on the magnitude of the load and the age and state of charge of the batteries.

WARNING

Only qualified technicians or supervised personnel should remove and/or replace the batteries. Batteries have a high short-circuit capacity: MISTAKES IN CONNECTING OR DISCONNECTING CAN CAUSE CONNECTIONS TO ARC OR WELD AND COULD RESULT IN SEVERE BURNS. DO NOT TOUCH UNINSULATED BATTERY TERMINALS. Otherwise, maintenance personnel may be exposed to an electrical shock hazard that could result in death or injury or damage to the UPS or its electrical loads.

Adding Battery Packs to Your UPS: Additional battery packs may be added to your UPS to extend the battery time provided by the internal batteries of your UPS (consult the specifications portion of this manual to determine maximum capacity that can be added to your particular UPS). It is recommended that only battery packs and cabling supplied by Mesta Electronics be added so that complete compatibility with your UPS can be guaranteed. Different manufacturer's battery packs may possibly used, but their use should be cleared with Mesta before doing so. Only qualified technicians should attempt connecting a battery pack other than the Mesta BP9-6.5 to your UPS. **CAUTION** - not clearing other battery packs with Mesta may result in serious damage to the UPS and/or the battery pack.

Mesta Battery Pack model number BP9-6.5 is custom designed to mate with all UPS models covered by this manual. The BP9-6.5 comes with all power cabling necessary to mate with the UPS. The BP9-6.5 is made to fit under the UPS (a maximum of **ONE** battery pack is allowed beneath a UPS). Should there be more than one extra battery pack, the battery pack units can be stacked one above the other next to the UPS (a maximum of **THREE** battery packs may be stacked in this fashion).

To connect one or more BP9-6.5 battery packs to a UPS perform the following steps:

1. Verify that the breaker on the back of each battery pack is turned off. Also, verify that the UPS is off and unplugged from the AC power. If battery packs are already installed with the UPS, make sure the breaker on each of these packs is off as well.
2. Locate the battery packs in the position that has been chosen, either under or to the side of the UPS.
3. Plug either end of the battery power connector (shipped with the battery pack) into one of the two receptacles on the back of the battery pack. The side of the connector marked "UPS" should be facing up away from the floor. The connector is keyed so that it doesn't fit any other way.
4. Plug the other end of the battery power connector into the "External Battery Connector" on the UPS.. If battery packs are already connected to the UPS, plug the battery packs into the

unused connector of any of the installed battery packs instead of any of the installed battery packs instead of the UPS connector.

5. Repeat steps 3 and 4 above until all battery packs have been installed.
6. Turn on the breaker on the back of each battery pack. Immediately consult factory if breakers trip off while attempting this.
7. Plug UPS into the AC power source. At this time you are ready to turn the UPS on.

Instruction for Removing UPS Battery Tray:

WARNING

Only qualified technicians or supervised personnel should remove and/or replace the batteries. Batteries have a high short-circuit capacity: MISTAKES IN CONNECTING OR DISCONNECTING CAN CAUSE CONNECTIONS TO ARC OR WELD AND COULD RESULT IN SEVERE BURNS. DO NOT TOUCH UNINSULATED BATTERY TERMINALS. Otherwise, maintenance personnel may be exposed to an electrical shock hazard that could result in death or injury or damage to the UPS or its electrical loads.

Mesta has designed this unit to provide maximum battery reliability, thus requiring little or no maintenance. However, should a battery problem be detected, please adhere to the following instructions and preceding warnings. The unit has been designed to allow easy access and replacement of the batteries by a qualified technician or supervised personnel.

Removing the battery tray necessitates opening the front door of the unit. Follow the procedure for opening the UPS outlined in the "**Internal Maintenance**" section of this manual. The following precautions should be observed while working on batteries:

- 1) Remove watches, rings, or other metal objects.
- 2) Use tools with insulated handles.
- 3) Do not lay tools or metal parts on top of batteries.
- 4) Do not touch battery terminals to chassis (watch for inadvertent contact that can occur if not being careful when removing lead wires to battery terminals).


After opening the front door of the UPS, unfasten the battery chassis by unscrewing the screw on the right side of the battery tray. Slide the tray out approximately 6 inches. Remove the black wire marked "B-" from the front left battery. Slide the battery tray out far enough to access the white wire marked "B+" attached to the rear right battery. Continue sliding the tray completely out of the unit. Do not slide the tray along the floor or other surface, as doing so may damage the battery holding straps. The tray must be carried or rolled on rollers and not slid whenever possible. (Round wooded dowels or spare screwdrivers may be used as rollers.

After the battery tray is removed from the cabinet, individual batteries may be disconnected and replaced, or the entire tray of batteries may be replaced. Exercise extreme caution to insure that batteries are replaced correctly, insuring proper battery polarities (consult figure 1 for correct wiring). Batteries must be secured back onto the tray using methods similar to the strapping and fasteners originally supplied.

To reinsert battery tray back in UPS, first make sure the ends of the "B+" and "B-" I{S wires are accessible. Line up the tray as shown in figure 1 (being careful to note the position of the tray mounting hole, "+" and "=" battery terminals). Align the tray with the internal UPS battery slides.

Lift the back of the tray (you may use the back most battery strap to lift the tray if you wish) and set the back of the tray in the internal battery slides. Attach the white "B+" wire to the "+" terminal of the rear right battery. Lift the front of the battery tray and gently push it into the UPS, insuring that the tray is within the slides of the UPS. Reattach the "B-" wire to the "-" terminal of the front left battery before the tray is fully pushed in. Then push the tray in completely until the tray mounting hole lines up with the hole on the right slide of the UPS. Thread the screw into the slide and tighten.

Figure 1: UPS Battery Tray Configuration



9. TROUBLESHOOTING

In the case of a UPS shutdown check the status of the front panel lights before attempting to restart the system. This information is critical in determining why the UPS shut down.

1. Check and record the status of each of the four front panel lights. (on, off, flashing)
2. If the OVERLOAD light is on and the UPS ON light is flashing the system shut down due to an overload.
3. If all four front panel lights are flashing the system has gone into a diagnostic mode.
4. If the system is in a diagnostic mode press and hold the reset button and record the status of the four front panel lights. (on, off, flashing)
5. If the system is in a diagnostic you may also check the fault status indication through the RS232 communications interface.
6. At this point it is recommended that you contact a Mesta representative for assistance.

APPENDIX A. UPS SPECIFICATIONS BY MODEL

This section of the Mesta Electronics Owner's Manual contains the full set of operating specifications for each of the models covered herein.

UPS Models

UPS1000 • 1KVA/KW
UPS1500 • 1.5KVA/KW
UPS2000 • 2.0KVA/KW

UPS1000 • 1KVA/KW ON LINE UPS SPECIFICATIONS

INPUT

Voltage • 120VAC - 15% + 10%

Frequency • 60Hz \pm 5Hz (Input voltage and frequency range are programmable via RS232 port)

OUTPUT

Voltage (AC line) • 120VAC \pm 5%
Voltage (on inverter) • 120VAC \pm 1%
Crest Factor Capability • 3.0
Output Power Factor Limitations • None
Frequency (AC line) • follows input
Frequency (on inverter) • 60Hz \pm .01Hz
Frequency Slew Rate • 1-255Hz/sec
(programmable via RS232 port)
Total Harmonic Distortion < 1%
Efficiency • >92% overall at full load
Overload Rating • 150% for 1 min.
• 275% for 5 sec.

OVERLOAD PROTECTION

Output electronically current limited to 275% full load rating
Fuses provide backup protection to electronic current limit
Over temperature protection

BATTERY

Sealed maintenance-free 5 year expected life
Battery voltage • 108VDC nominal
Battery current • 11.4 amps max
Backup time • 20 min. on internal batteries (full load)

INDICATORS AND CONTROLS

LEDs • Indicate AC line, Inverter, Battery, and Overload status
Audible alarm • indicates loss of AC line, low battery, or overload
Reset Switch • silences alarm and resets overloads
Power ON/OFF switch
RS232 Interface for remote communications of status and diagnostics

PHYSICAL (1KVA)

Operating Temp • 0° C-40° C ambient without derating
Storage Temp • 20° C-40° C
Thermal • no cooling fan required
Audible Noise • 35 dBA
Line Cord • 6' black 3 wire ground with NEMA 5-15 plug
Output Receptacles • 4 NEMA 5-20R
RS232 Port • Interface for remote communications
Dimensions: • Height 18"
• Length 21.5"
• Width 10.5"
Weight with internal batteries • 135 lbs.
Color • PC Bone

OPTIONS

External Battery Cabinets • For extended backup times (Model BP9-6.5)
Maximum allowable external battery capacity - equivalent of 10 packs
Casters (Option -C)
50 Hz Models

NOTE: For any of the above options, consult factory.

UPS1500 • 1.5KVA/KW ON LINE UPS SPECIFICATIONS

INPUT

Voltage • 120VAC - 15% + 10%

Frequency • 60Hz \pm 5Hz (Input voltage and frequency range are programmable via RS232 port)

OUTPUT

Voltage (AC line) • 120VAC \pm 5%

Voltage (on inverter) • 120VAC \pm 1%

Crest Factor Capability • 3.0

Output Power Factor Limitations • None

Frequency (AC line) • follows input

Frequency (on inverter) • 60Hz \pm .01Hz

Frequency Slew Rate • 1-255Hz/sec
(programmable via RS232 port)

Total Harmonic Distortion < 1%

Efficiency • >92% overall at full load

Overload Rating • 150% for 1 min.
• 275% for 5 sec.

OVERLOAD PROTECTION

Output electronically current limited to 275% full load rating

Fuses provide backup protection to electronic current limit

Over temperature protection

BATTERY

Sealed maintenance-free 5 year expected life

Battery voltage • 108VDC nominal

Battery current • 16 amps max

Backup time • 12 min. on internal batteries (full load)

INDICATORS AND CONTROLS

LEDs • Indicate AC line, Inverter, Battery, and Overload status

Audible alarm • indicates loss of AC line, low battery, or overload

Reset Switch • silences alarm and resets overloads

Power ON/OFF switch

RS232 Interface for remote communications of status and diagnostics

PHYSICAL (1.5KVA)

Operating Temp • 0° C-40° C ambient without derating

Storage Temp • 20° C-40° C

Thermal • no cooling fan required

Audible Noise • 35 dBA

Line Cord • 6' black 3 wire ground with NEMA 5-20P plug

Output Receptacles • 4 NEMA 5-20R

RS232 Port • Interface for remote communications

Dimensions: • Height 18"
• Length 21.5"
• Width 10.5"

Weight with internal batteries • 150 lbs.

Color • PC Bone

OPTIONS

External Battery Cabinets • For extended backup times (Model BP9-6.5)

Maximum allowable external battery capacity - 1 pack

Extended battery runtime (Option -X) allows max equivalent of 15 packs

Casters (Option -C)

50 Hz Models

NOTE: For any of the above options, consult factory.

UPS2000 • 2KVA/KW ON LINE UPS SPECIFICATIONS

INPUT

Voltage • 120VAC - 15% + 10%
Frequency • 60Hz \pm 5Hz (Input voltage and frequency range are programmable via RS232 port)

OUTPUT

Voltage (AC line) • 120VAC \pm 5%
Voltage (on inverter) • 120VAC \pm 1%
Crest Factor Capability • 3.0
Output Power Factor Limitations • None
Frequency (AC line) • follows input
Frequency (on inverter) • 60Hz \pm .01Hz
Frequency Slew Rate • 1-255Hz/sec
(programmable via RS232 port)
Total Harmonic Distortion < 1%
Efficiency • >92% overall at full load
Overload Rating • 150% for 1 min.
• 275% for 5 sec.

OVERLOAD PROTECTION

Output electronically current limited to 275% full load rating
Fuses provide backup protection to electronic current limit
Over temperature protection

BATTERY

Sealed maintenance-free 5 year expected life
Battery voltage • 108VDC nominal
Battery current • 22 amps max
Backup time • 8 min. on internal batteries (full load)

INDICATORS AND CONTROLS

LEDs • Indicate AC line, Inverter, Battery, and Overload status
Audible alarm • indicates loss of AC line, low battery, or overload
Reset Switch • silences alarm and resets overloads
Power ON/OFF switch
RS232 Interface for remote communications of status and diagnostics

PHYSICAL (2KVA)

Operating Temp • 0° C-40° C ambient without derating
Storage Temp • 20° C-40° C
Thermal • no cooling fan required
Audible Noise • 35 dBA
Line Cord • 6' black 3 wire ground with NEMA 5-30P plug
Output Receptacles • 4 NEMA 5-20R
RS232 Port • Interface for remote communications
Dimensions: • Height 18"
• Length 21.5"
• Width 10.5"
Weight with internal batteries • 150 lbs.
Color • PC Bone

OPTIONS

External Battery Cabinets • For extended backup times (Model BP9-6.5)
Maximum allowable external battery capacity - 1 pack
Casters (Option -C)
50 Hz Models

NOTE: For any of the above options, consult factory.

APPENDIX B. WARRANTY/SERVICE AND REPAIR

LIMITED WARRANTY POLICY

Mesta Electronics, Inc. warrants its UPS to be free from defects in materials and workmanship for a period of 1 year from the date of original shipment from the factory, provided the UPS has not been abused, misused, or used outside of the specified conditions. Mesta Electronics, Inc. will be the sole determiner as to whether the UPS has been abused or misused. If found to be defective, the UPS will be repaired or replaced at the discretion of Mesta Electronics, Inc. An extended warranty may be purchased. The battery manufacturer's warranties are passed through by Mesta Electronics, Inc. to the customer. Before returning any UPS, in or out of warranty, to Mesta Electronics, purchaser must contact Mesta's Customer Service Department. Any UNAUTHORIZED return of an UPS to Mesta Electronics for in-warranty or out-of-warranty repairs will be subject to a \$250 inspection and handling charge in addition to all associated repair and transportation costs. Mesta Electronics, Inc. will be in no way responsible for any consequential damages of any kind or nature whatsoever resulting from the use of its UPS in any manner whatsoever and/or from the breach of any warranty, express or implied.

Mesta Electronics, Inc.

The foremost name in power protection!



MESTA ELECTRONICS, INC.
11020 Parker Drive ■ N. Huntingdon, PA 15642
412/754-3000